



Standing Magnifier Lamp



Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
- Do not stare at the light tube when it is on, this will damage your eyes.
- There are no user serviceable parts.
- Do not use if any of the wires or the plug are damaged or exposed.
- This product is not a toy, and is only to be used for its designated purpose.
- To protect against electrical shock, do not immerse cord, plug or any part of this appliance in water or any other liquid.
- Never operate electrical appliance in immediate vicinity of water sources.
- Ensure the power supply to the socket into which the appliance is plugged, is in accordance with the rating label on the appliance and that the socket is earthed.
- When the appliance is not in use, always unplug from the mains socket.
- Ensure the machine is securely installed before operation.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Please retain a copy of all instructions for future consultation.

Operating Instructions

- Open the carton and take out the castor feet. Install the two metal stability forks and insert the supporting column in the middle. Install the screw into the bottom and tighten to stabilise.
 - The magnifier glass comes assembled to the holder. This just needs fixing to
 - the base that you have previously assembled
-
- Adjust the magnifying glass to the desired angle.
 - NEVER stare at the light source as this will damage your eyes.
 - Turn on the power switch and start operating the machine after the bulb lights up.



An Official Oypla Branded Product

Imported into the EU by Oypla.com LLP, Uxbridge, UB8 2FX

