

OYPLaTM DIY



*COLOUR MAY VARY

Carpet Knee Kicker

USER MANUAL Model No: 3337, 3338

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is not a toy, and is only to be used for its designated purpose.
- Never carry out any alterations or modifications to this product.
- This product is intended for indoor use only.
- Only use this product on stable, level and dry ground.
- Do not wear loose clothing or jewellery whilst using the product as they could be caught whilst the product is in use.
- Before using the product, inspect it to make sure that no parts are damaged or broken. If any part of the product is damaged it should be repaired or replaced by a qualified technician, replaced or returned.
- Always wear PPE when working with this product.
- Do not use this product in damp or wet locations.
- This product is not intended for use by persons (including children) with reduced physical, sensory and mental capacities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by persons responsible for their safety.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances or abrasive materials as these will damage the product.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Operating Instructions

Operation

1. Squeeze both of the adjustment buttons on the side of the handle bar and adjust the handle to the desired length. Release the adjustment buttons and the handle should hold itself into the released position.

2. Remove the protective cover found on the pins.

3. Turn the pin adjustment knob (found on the front of the carpet knee kicker) to the proper length for the carpet you are working with. The pin adjustment knob has seven settings, with the lower numbers standing for shorter pin lengths whilst the higher numbers are for the longer pin lengths. Turn the adjustment knob clockwise to decrease the pin length and counter-clockwise to increase the pin length.

NOTE: The pin length must be substantial enough to go through the top of the carpet and into the cloth-like backing, but not go through the back and into the pad as this will damaged the under layer of the carpet.

4. Position the carpet knee kicker next to the tack strips with the pins properly inserted into the carpet and carpet backing. Push your knee against the knee pad to move the carpet onto the tack strips. Press the carpet down onto the tack strips to secure it. Continue along the perimeter, repeating this step as you go along.

When you are finished, use the pin adjustment knob to fully retract the pins and place the protective cover back over them. Make sure the protective cover is secure. The nicks on the protective cover should be facing the handle.

Care and Maintenance

- Be sure to clean the carpet knee kicker regularly, removing any dirt or debris from the pins and grip pad.
- Once the grip pads have worn down and need replacing, remove the two cross-head screws that hold the grip pad into place and install a new grip pad.

NOTE: Always ensure that the grip pads have been and are secured correctly before using.

- Never use oil on the pins or grip pads as this may cause discolouration or stain the carpet.

HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP
CONTACT THEM VIA:

TELEPHONE: 020 3600 2255

EMAIL: cservice@oypla.com

LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION

OYPLA.COM

An Official OYPLA Branded Product

Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 3337, 3338