



Convector Heater

Safety Instructions


Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Do not use the heater unless the feet are correctly attached.
- Ensure the power supply to the socket into which the heater is plugged is in accordance with the rating label on the heater and that the socket is earthed.
- Keep the power cord away from the hot body of the heater.
- **WARNING!** Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
- Indoor use only.
- Do not place the heater on carpets having a very deep pile.
- Always ensure that the heater is placed on a firm level surface.
- Do not place the heater close to curtains or furniture in order to avoid a fire hazard.
- **WARNING!** Do not place the heater immediately below a socket-outlet.
- Do not insert any object through the heat outlet or air grilles of the heater.
- Do not use the heater in areas where flammable liquids are stored or where flammable fumes may be present.
- Always unplug the heater when moving it from one location to another.
- **WARNING!** If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Operating Instructions

Before using the heater, the feet must be fitted to the unit. These are to be attached to the base of the heater using the 4 self-tapping screws provided, taking care to ensure that they are located correctly in the bottom ends of the heater side mouldings.



Note: It is normal when the heaters are turned on for the first time or when they are turned on after having not been used for a long period of time to emit some smell and fumes. This will disappear when the heater has been on a short while.

Operating your Heater

- Choose a suitable location for the heater and insert the plug of the heater into a suitable socket.
- Turn on the thermostat knob fully in a clockwise direction to the maximum setting
- Turn on the heating elements by means of the rocker switched on the side panel. When the heating elements are on the switched will illuminate. For maximum heat output both switched should be on. When the desired room temperature has been reached, the thermostat knob should be turned slowly anti-clockwise until the thermostat is heard to click off and the lights on the element switches are seen to go out. After this the heater will keep the air temperature in the room at the set temperature by switching on and off automatically.
- In its minimum (fully anti-clockwise) position, the thermostat provides a frost guard position. In this position (depending on the size of the room) the heater will maintain the temperature above freezing.

INFORMATION REQUIREMENTS FOR ELECTRIC LOCAL SPACE HEATERS

Model Identifier	40				
Item	Symbol	Value	Unit	Item	Unit
Heat Output				Type of heat input, for electric storage local space heaters only (select one)	
Nominal Heat Output (Indicative)	P_{nom}	1.8-2.0	kW	Manual Heat charge, with integrated thermostat	N/A
Minimum continuous heat output	P_{min}	0.75	kW	Manual heat charge control with room and/or outdoor temperature feedback	N/A
Maximum continuous heat output	P_{max}	2	kW	Electronic heat charge control with room and/or outdoor temperature feedback	N/A
Auxiliary electricity consumption	/	/	/	Fan assisted heat output	N/A
At nominal heat output	e_{lmax}	0	kW	Type of heat output/room temperature control (select one)	
At minimum heat output	e_{lmin}	0	kW	Single stage heat output and no room temperature control	[no]
In Standby mode	e_{lsb}	0	kW	Two or more manual stages, no room temperature control	[no]
				With mechanic thermostat room temperature control	[yes]
				With electronic room temperature control	[no]
				Electronic room temperature control plus day timer	[no]
				Electronic room temperature control plus week timer	[no]
				Other control options (multiple selections possible)	
				Room temperature control, with presence detection	[no]
				Room temperature control, with open window detection	[no]
				With distance control option	[no]
				With adaptive start control	[no]
				With black bulb sensor	[no]

⚡ WARNING ⚡

To reduce the risk of fire, electric shock or injury to persons or property follow these basic precautions when using the heater:

- Read all instructions before using the heater.
- Never allow children to operate or play with the heater.
- Never clean heater parts with flammable fluids. The fumes can create a fire hazard or explosion.
- Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other heater. The fumes can create a fire hazard or explosion.
- UNPLUG OR DISCONNECT THIS HEATER FROM THE POWER SUPPLY BEFORE SERVICING.

-Save these instructions-

Storing the Heater

When the heater is not used for long periods of time it should be protected from dust and stored in a clean dry place.

Cleaning the Heater

Always un-plug the heater from the wall socket and allow it to cool down before cleaning.

Clean the outside of the heater by wiping with a damp cloth and buff with a dry cloth.

Do not use any detergents or abrasives and do not allow any water to enter the heater.

Please retain a copy of all instructions for future consultation.



An Official Oypla Branded Product



Imported into the EU by Oypla.com LLP, Uxbridge, UB8 2FX

Environmental Protection

Products bearing the symbol shown above means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.