

OYPLATM DIY



Grout Remover Tool

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- The product should only be connected to a 240 V AC, 50 Hz electrical outlet.
- Never leave the product unattended whilst it is switched on.
- If you have to leave the product unattended, even for a short while, always switch it off.
- Keep the product out of children's reach and do not allow children to use it.
- Never use near flammable materials or gasses.
- Inspect the mains lead regularly. Never use the product if the mains lead or plug has been damaged in any way.
- Do not place the mains lead on or near any hot surface.
- Do not touch the product if your hands are moist or wet.
- Wear protective gloves and goggles when operating.
- Remove any adjusting key before turning the tool on. An adjusting key left attached to the rotating part of the tool may result in personal injury.
- Do not overreach. Keep proper footing and balance at all times
- Never hold the piece being cut in your hands or across your leg. Secure the work piece to a stable platform.
- Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts.
- Always turn off and unplug the power tool before making any adjustments, changing accessories or storing the tool
- Wear dust protection during use, breathing in the dust can be hazardous to your health.
- Do not overload the tool – allow the tool to do the work.

⚡ WARNING ⚡	To Reduce The Risk of Fire or Electric Shock, follow these basic precautions:
<ul style="list-style-type: none">● Read all instructions before using this tool.● Never allow children to operate or play with this tool.● Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this tool. The fumes can create a fire hazard or explosion.● UNPLUG OR DISCONNECT THIS TOOL FROM THE POWER SUPPLY BEFORE SERVICING.	
-Save these instructions-	

Operating Instructions

USER INSTRUCTIONS (Please keep these instructions)

Product Details



Operating Instructions

Make sure the grout removal/engraving tip is securely in place before using the tool.

You may find it helpful to practice on scrap material before you begin and adjust the stroke adjustment dial to find the level of stroke you require. A fine stroke will be gained from setting the dial to "1" and a thick stroke from setting the dial to "5".

- Plug the power lead into the mains power supply and switch the mains power supply on at the socket.
- Hold the tool securely at an angle, as you would hold a pen.
- Switch the on/off button to the "I" position.
- Position the tool at the point where you wish to begin removing the grout or start engraving.
- **DO NOT** push down hard when removing grout or engraving, use light pressure while guiding the point over the work.
- Lift the tool from your work as you finish each stroke. When you have completed your work, switch the on/off button to the "O" position. Switch off the mains power supply at the socket and remove the power lead from the mains supply.
- **NOTE:** Always ensure the product is switched off at the mains power supply before making any adjustments or maintenance procedures.
- **DO NOT** operate the tool for more than 10 minutes at any one time. Allow the tool to cool for 20 minutes before recommencing use.

Grout Removal:

- Prior to using the grout removal tool in a bathroom, make sure that all fittings such as cabinets, mirrors, towel rails and shelving around the work area are removed. Sinks and taps should be covered with a work sheet to avoid damaging them during work.
- Water should not be in the sink in either a kitchen or bathroom when using the grout removal tool. Toilet lids and tanks in bathrooms should remain closed and covered during work.
- If the tool is dropped into water **DO NOT** reach in to remove it. Switch off at the wall socket and unplug before removing. The tool will need to be assessed by a suitably qualified person before using again.
- Use the correct tip for the type of tiles being worked on – use the pointed tip for smaller tiles and the flat tip for larger tiles. Smaller tiles of 10cm square will hold less grout than larger tiles of 30cm square and accordingly the width and depth of the grout will be less.
- Only remove 2-3mm of grout leaving a firm base for refilling. Practice on a small area to confirm the correct amount is removed.
- Use a soft brush to remove any accumulated dust. Wear safety glasses to protect your eyes whilst brushing out any dust or debris.

Installing or Replacing a Grout Removal/Engraving Tip):

NOTE: Ensure the tool is disconnected from the mains power supply before you make any adjustments or carry out any maintenance procedures.

1. Loosen the tip release screw (4) using the provided allen key by turning it anticlockwise.
2. Place the grout removal/engraving tip through the centre of the hole of the tool, ensuring the tip fully enters the tool housing.
3. The tip should protrude from the end of the housing by approximately 16mm.
4. Tighten the tip release screw using the provided allen key by turning it clockwise.

Care and Maintenance

If you need to clean the body of the tool, wipe with a damp cloth. Water must never come into contact with the tool or strong cleaning agents as they may cause damage to the product.

USER INSTRUCTIONS (Please keep these instructions)

Specifications

Rated Voltage: 240V AC, 50Hz
Power: 13W
No-Load Speed: 6000rpm

Sound Pressure L_{PA} : 73.8dB(A)
Sound Pressure L_{WA} : 84.8dB(A)
Uncertainty K: 11dB(A)
Weighted Vibration a_h : 4.981m/s²
Uncertainty K: 1.5m/s²

WARNING: User exposure to tool vibration can result in loss of sense of touch, numbness, tingling and reduced ability to grip. Long term exposure can lead to a chronic condition. If necessary, limit the length of time exposed to vibration and use anti-vibration gloves. Do not operate the tool with hands below a normal comfortable temperature, as vibration will have a greater effect. Use the figures provided in the specification relating to vibration to calculate the duration and frequency of operating the tool. Sound and vibration levels in the specification are determined according to EN60745 or similar international standards. The figures represent normal use for the tool in normal working conditions. A poorly maintained, incorrectly assembled, or misused tool, may produce increased levels of noise and vibration. www.osha.europa.eu provides information on sound and vibration levels in the workplace that may be useful to domestic users who use tools for long periods of time.

Disposal of Unit

Appliances bearing the symbol shown here may not be disposed of in domestic rubbish. You are required to dispose of old electrical and electronic appliances like this separately. Please visit www.recycle-more.co.uk or www.recyclenow.co.uk for access to information about the recycling of electrical items. Please visit www.weeeireland.ie for access to information about the recycling of electrical items purchased in Ireland. The WEEE directive, introduced in August 2006, states that all electrical items must be recycled, rather than taken to landfill. Please arrange to take this appliance to your local Civic Amenity site for recycling, once it has reached the end of its life.



HAVE A QUESTION ABOUT YOUR PURCHASE?

OUR DEDICATED CUSTOMER SERVICES TEAM ARE HAPPY TO HELP
CONTACT THEM VIA:

TELEPHONE: 020 3600 2255

EMAIL: cservice@oypla.com

LIVE CHAT: www.oypla.com

PLEASE RETAIN A COPY OF THESE INSTRUCTIONS FOR FUTURE CONSULTATION



Environmental Protection

Products bearing the symbol shown below means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.



OYPLA.COM

An Official OYPLA Branded Product



Imported by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 4043