

User Manual

OYPLATM

LEISURE



14L Cool Bag

CE

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- This product is not a toy, and is only to be used for its designated purpose.
- Do not carry out alterations or modifications to this product.
- Clean only with a damp cloth. Do not use strong industrial cleaning substances.
- Leaving the product outside exposed to weather, especially direct sun and rain, will speed the weathering process. This can be slowed by removing the product from these conditions.
- Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- This product is not intended for use by persons (including children) with reduced physical, sensory and mental capacities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by persons responsible for their safety.
- Please ensure the 12V plug is disconnected from the DC socket after the engine is turned off.
- Keep the appliance away from flammable items and dampness to prevent any electrical failure and fire.
- Please unplug the 12V plug from the DC socket when the cooler is not in use.
- Prevent any obstructions to the fan. If the fan becomes blocked, it can overheat and cause fire. Never cover with towels or cloths.
- Please ensure the sockets of the cords are inserted firmly. A loose fitting can result in the cord and sockets over-heating and failing.
- Avoid turning the cooler upside down.
- Children should be supervised to ensure that they do not place with the appliance.
- Do not use electrical appliances inside the food storage compartments.
- Please note, raw food or seafood cannot be put in this appliance directly. Packaging for this kind of food is required.
- This product is for domestic use only.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Operating Instructions

1. Characteristics of our Products

This electric cool/hot box can bring you cool drinks in the summer and warm food in the winter. No matter whether on a long car journey, or outdoor hiking stuck in your car, you can enjoy plenty of drinks and foods at their optimum temperature. Not only can this product box be used in the car, it can also be used indoors, making transporting this cool/hot box easy due to its lightweight style.

It integrates dual functions of cooling and heating by employing a semiconductor, without compressor or cryogen. It has advantages of being free from pollution (no harmful gasses), small volume, light weight, portable, long service life and lowest power consumption.

2. Application

For holding banquets beside the lake	In students dormitory or dining hall	For travelling by cars	For preservation of fresh milk and cool food
For picnics and on camping trips	In playgrounds	On yacht outing or going fishing	For home beer
For taxi drivers	In the office or construction site	In wagon, truck or travelling bus	

3. Performance

For optimum cooling effect, we suggest using pre-chilled foods and drinks.

Please note the appliance is not suitable for storing ice cream or to freeze food or beverages.

4. Operating Guide

Check the power rating of the car before use.

Insert the plug of the cigarette lighter into the cigarette lighter in the car.

The cooler will start automatically.

Troubleshooting

If the appliance is not operating (plug is inserted).	The ignition must be switched on in most vehicles for voltage flow at the cigarette lighter.
If the appliance does not cool (plug is inserted).	Contact supplier for advice as the motor may be at fault.
If the appliance does not cool but the fan is rotating normally.	Contact supplier for advice as the cooling system may be at fault.
If the ignition is on and the cooler is not working. Remove the plug and make the following checks.	The fuse of the 12V plug has blown. Replace the fuse. The vehicle socket fuse has blown. Replace the fuse.

Environmental Protection

Products bearing the symbol shown above means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection points where it will be accepted free of charge. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.

Please retain a copy of all instructions for future consultation.



An Official Oypla Branded Product

Imported into the EU by Oypla.com LLP, Uxbridge, UB8 2FX



USER MANUAL Model No: 4304

