



Tyre Gauge

Safety Instructions

Notice: Ensure you read and fully understand instructions before use

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

- Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.
- Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- Use the correct fixings as indicated.
- Do not carry out alterations or modifications to this product.
- Persons (including children) with reduced physical, sensory and mental capacities or lack of experience and knowledge do not intend this product for use, unless persons responsible for their safety have given them supervision or instruction concerning use of the product.
- This product is not a toy, this product is only to be used for its designated purpose.
- Keep out of reach of children.
- Dropping or exposing the gauge to harsh vibrations may affect its operation.
- Testing pressures above 100psi will cause permanent damage to the gauge.
- Using the gauge in extreme temperatures may affect pressure readings.
- If the product is damaged or has any defects, please contact cservice@oypla.com

Operating Instructions

1. Remove valve cap.
2. Make sure valve is clean.
3. Place end of tire gauge onto the valve and depress.
4. Check pressure reading on dial
5. To reset gauge to zero press the air release valve
6. If needed, press the release valve to lower pressure on overinflated tires.

**Please retain a copy of all instructions for future
consultation.**



An Official Oypla Branded Product

Imported into the EU by Oypla.com LLP, Uxbridge, UB8 2FX

USER MANUAL Model No: 4580